



### **Purpose**

This document provides guidance on utilizing the OCT analysis functionality available within OptosAdvance™ for MonacoPro devices outside of the United States.

Not all products, services, or offers are approved or available in every market. Approved labeling and instructions may vary from one country to another. For country specific product information, see the appropriate country website or Instructions for Use (IFU).

NOTE: Full operating instructions and device warning and cautionary messaging are provided in the Instructions for Use. Please review the IFU (G-108707) prior to operating the device. The IFU can be found at <a href="https://example.com/IFU">optos.com/IFU</a>. Scan the QR Code below for direct access:





### Contents

Purpose	1
Segmentation Generation	
Segmentation View	
Retinal Thickness Analysis	
Ganglion Cell Complex (GCC) Analysis	
Optic Nerve Head (ONH) Analysis	5
Retinal Nerve Fiber Layer Analysis	
Retina, GCC, ONH, and RNFL Reports	
OCT Views	
3D Views	8
Radial Views	9
Explorer Views	9
Standard B-Scan Views	10
Comparing OCT Scans from Multiple Visits	





### **Segmentation Generation**

Segmentation reports are generated by capturing Retina Topography and/or ONH Topography scans on the device. Colorized reference data will display for patients 22 years and older.

ONH Topography scan capture will provide:


- ONH Cup/Disk metrics and ONH Nerve Fiber thickness map (ONH)
- Retinal Nerve Fiber Layer thickness profile (RNFL)

Retina Topography scan capture will provide:

- Total Retinal Thickness map (TRT)
- Ganglion Cell Complex thickness map (GCC)

## **Segmentation Report View**

- 1 | Select the **Hanging Protocols** icon (Hang. Prot.) from the toolbar.
- 2 | Locate the **Monaco Seg** header menu option. The stages of views are shown underneath.
  - a. RG: Displays the RG optomap®
  - b. AF: Displays the AF optomap
  - c. TRT: Total Retinal Thickness Analysis
  - d. GCC: Ganglion Cell Complex Analysis
  - e. ONH: Optic Nerve Head Analysis
  - f. RNFL: Retinal Nerve Fiber Analysis
- 3 | Select the Next button on the toolbar or use your right arrow key on your keyboard to advance to each stage of the Hanging Protocol. You can also manually select each stage from the Hanging Protocol icon to navigate.
- 4 | To remove the segmentation lines on the scans, select the Titles tool from the toolbar, and choose Segmentation Overlay.
- 5 | There are additional OCT views available from the Hanging Protocol menu that do not contain analysis reports. They will not contain the Monaco Seg menu header. See Section Standard B-Scan Views.












## **Total Retinal Thickness Analysis**

Hanging Protocol: TRT (Total Retinal Thickness)

Tips for reviewing the TRT:

- The retinal thickness is based on ILM → RPE
- To evaluate quality of the scan, ensure that scan capture placement is correct. Retina Topography scan should be centered on the macula area. The B-scan should be oriented correctly and not upside down. SNR values of 6 and above offer more reliable segmentation measurements.
- Scroll through volume scans (5 and 6) using the scroll wheel on your mouse to view all 97 B-scans.
- Contour, Grid, and Edit tools are accessible via the **View Tools** icon on the left side menu.



1	SLO with thickness map view	5	Vertical B-Scan (extracted)
2	9-field ETDRS grid (6mm)	6	Horizontal B-Scan
3	Thickness color gauge	7	Individual B-Scan SNR
4	Average Volume SNR value	8	ETDRS value table

Page **3** of **12** GA-00401/4






## Ganglion Cell Complex (GCC) Analysis

Hanging Protocol: GCC

Tips for reviewing the GCC:

- GCC thickness is based on ILM →IPL Boundary (NFL, GCL, IPL)
- To evaluate quality of the scan, ensure that scan capture placement is correct. Retina Topography scan should be centered on the macula area. The B-scan should be oriented correctly and not upside down. SNR values of 6 and above offer more reliable segmentation measurements.
- If the 6-field grid (2) is not centered on the fovea, hover over its center until you see a square in the box and move this to the correct location.
- Scroll through volume scans (5 and 6) using the scroll wheel on your mouse to view all 97 B-scans.
- Contour, Grid, and Edit tools are accessible via the **View Tools** icon on the left side menu.



1	SLO with thickness map view	5	Vertical B-Scan (extracted)
2	GCC 6 field grid (6mm)	6	Horizontal B-Scan
3	Thickness color gauge	7	Individual B-Scan SNR
4	Average Volume SNR value	8	6 field grid value table

Page **4** of **12** GA-00401/4






### **Optic Nerve Head Analysis**

Hanging Protocol: ONH

Tips for reviewing the ONH:

- ONH analysis is based on Bruch's Membrane Opening (BMO) and Minimum Rim Width (MRW).
- To evaluate quality of the scan, ensure that scan capture placement is correct. ONH Topography scan should be centered on the optic nerve head. The B-scan should be oriented correctly and not upside down. SNR values of 6 and above offer more reliable segmentation measurements.
- The Nerve Fiber thickness map is shown by default (1). You can toggle the NFL thickness map on/off within the View Tools menu option.
- NFL thickness map on/off and edit tools are accessible via the **View Tools** icon on the left side menu.



- BMO points (disc) •
- Minimum Rim Width (MRW) O
- Editable BMO points and outlines

	1	SLO with thickness map & cup/disc outlines	4	Vertical B-Scan (extracted)
	2	Thickness color gauge	5	Horizontal B-Scan
Ī	3	Average Volume SNR value	6	ONH cup and disc metrics

Page **5** of **12** GA-00401/4






### Retinal Nerve Fiber Layer Analysis

Hanging Protocol: RNFL

Tips for reviewing RNFL:

- RNFL Analysis is based on the ILM>outer NFL boundary.
- Circle is a T-S-N-I-T sequence.
- RNFL is auto extracted from the ONH Topography scan.
- To evaluate quality of the scan, ensure that scan capture placement is correct. ONH Topography scan should be centered on the optic nerve head. SNR values of 6 and above offer more reliable segmentation measurements.
- Edit tools are accessible via the **View Tools** icon on the left side menu.



1	RNFL scan with segmentation	5	RNFL thickness line graph
2	Individual B-Scan SNR	6	12 segment graph values
3	Auto ONH center detection on SLO overlay	7	Average, Minimum, Maximum thickness
4	Average Volume SNR value	8	Quadrant and 12 segment wheel

Page 6 of 12 GA-00401/4





### TRT, GCC, ONH, and RNFL Reports

Hanging Protocol: OD OCT, OS OCT

This stage of the Hanging Protocol, displays all four analyses on one screen per eye, provided both the Retinal Topography and ONH Topography scans were captured.




1	Retinal thickness	3	GCC
2	ONH	4	RNFL

### **OCT Views**

There are multiple ways to view your reports. You can manually select an OCT view from the View tool.

- 1 | Select **View** from the toolbar.
- 2 | Locate the OCT Views header and select the applicable OCT view:
  - a. Retina
  - b. Retina GCC
  - c. ONH
  - d. RNFL

3D View, Radial View, and Explorer View are covered in subsections below.








#### **3D Views**

The 3D View is intended for use with Retina Topography and ONH Topography.

Open an OCT and select **View** from the toolbar, then select **3D**.


In this view are the following viewports:


- A enface/coronal view in the main (topleft) Multi-Plane Reformat (MPR) viewport
- Cross-sectional OCT images shown in the additional MPR viewports (bottomleft and top-right)
  - These represent different orientations, such as axial and sagittal.
- A 3D image is shown in the bottomright. In the 3D viewport, the tissue above the top layer and below the bottom layer has been removed for easier view of the layer depths.



To utilize the Plane Clipper tool, follow the steps below:

- 1 | Select View Tools from the left-hand menu.
- 2 | Beneath the Tools header, select the Plane clipper icon.
- 3 | To use the tool, click (or tap) the 3D image and then drag to push the plane in and out.





Page **8** of **12** GA-00401/4





### **Radial Views**

The Radial View allows you to scroll through fixed- angle cross sections that are extracted from a volume scan. The outline of the original raster volume scan is shown on the enface by a blue rectangular border in the right viewport.

Open an OCT and select **View** from the toolbar, then select **Radial**.

You can move the center point by clicking and dragging the white box to the desired location. Hover your mouse over the B-scan and scroll through the interpolated 'spokes'.

To update the number of spokes (6, 12, 24, 36, or 48), select **View Tools** from the left-hand menu.


Note: If the Radial View is not available for the scan type, it will be grayed out.



Explorer View allows you to see and select all available OCT scans taken on the same day. Explorer views are also available from the Hanging Protocol menu dropdown.

Open an OCT and select **View** from the toolbar, then select **Explorer**.

All available OCT scans will be highlighted on the **opto**map image. Select the scan you want to view from the **opto**map, and the right viewport will change to the corresponding OCT.





Page **9** of **12** GA-00401/4






### Standard B-Scan Views


To view a non-segmented series, change the Hanging Protocol to a non-segmented view. There are multiple customized views available for use depending on OCT review preferences.

- 1 | Select **Hanging Protocol** on the toolbar.
- 2 | Select a menu option without analysis:
  - a. Retina and Optic Nerve
  - b. Optic Nerve
  - c. Multimode
  - d. Explorer



\*Dotted lines can be toggled off/on by selecting Titles on the toolbar and selecting

**Segmentation Overlay** 








### Comparing OCT Scans from Multiple Visits

If scans were taken at previous visits, you can compare progressive changes over time within OptosAdvance. **The Hanging Protocol** menu options automatically come with stages to display the current capture and the most recent like prior study. These side-by-side comparisons are indicated by an asterisk (\*) in the menu stages. This example shows an RNFL side-by-side comparison.






### Scrolling Through Priors

To compare older prior scans side-by-side, follow the steps below. This example will show ONH OS comparison.

- 1 | Ensure your timeline displays HP Priors Scrolling.
- 2 | If HP Priors Scrolling is missing: Select the **Settings** icon.
- 3 | Navigate to System>Timeline and ensure Show HP Prior Navigation Panel is active. Select Save. Return to Directory.








- 4 | Open your desired study and confirm HP Priors Scrolling is displayed in the Timeline.
- 5 | Select a prior OCT report stage (indicated with an asterisk) to display a current OCT report, and the most recent prior report on the screen.



6 | Select the Forward button on HP Priors Scrolling to change the right viewport to display all the prior matching reports in your timeline.





7 | Take notice of the blue numbered circles in the timeline. The viewports will display the matching blue circle in the bottom corner of the heatmap view to indicate which date is showing

This functionality applies to all image modalities and OCT Analysis reports if the correct prior Hanging Protocol is selected first.

For additional information on comparing prior images, review the document titled **Optos Comparing Prior Images.** 



Optos UK/Europe +44 (0)1383 843350 **Optos North America** 800 854 3039 usinfo@optos.com

Optos DACH DE: 0800 72 36 805 AT- 0800 24 48 86 CH: 0800 55 87 39 ics@optos.com

Optos Australia +618 8444 6500 auinfo@optos.com



